


# CALISTA



**B1146AA**

Pos.	Signify	Spare parts-Nr.	Quantity	Pos.	Signify	Spare parts-Nr.	Quantity
1	Handle, w/logo-red	B961308AA	1 Set	12+11	Flow regulator 4 l/min.	A962570NU	1 Pcs.
1a	Handle, w/logo-blue	B961307AA	1 Set				
2	Screw M5x6		2 Pcs.				
3	Block cap	A961157AA	1 Pcs.				
4	Indicator-red		1 Pcs.				
4a	Indicator-blue		1 Pcs.				
5	Screw M4x8		2 Pcs.				
6	Adapter+screw	A861446NU	1 Set				
7	Ceramic valve G1/2,90°-RH	A861244NU*	1 Pcs.				
7a	Ceramic valve G1/2,90°-LH	A861243NU*	1 Pcs.				
8	Body pillar tap G1/2		2 Pcs.				
9	Flow straightener	B960998NU	2 Pcs.				
10	Connecting group	B960480NU	1 Set				
11	O-Ring Ø12.1x1.6		2 Pcs.				

\*Universal set (not all parts needed)