

---

Due to product evolution some ceramic tanks have changed configuration at the start of 2020, and therefore it will be necessary for you to identify the correct flushing valve spare and inlet valve spare by following the below steps:

1. Remove the tank lid
2. Find the marked water line (it should be where the water level is).
3. If the water line is above 250mm from the inside base of the cistern then your tank is the 2020 version

2020 Version spare outlet valve : EV495AA Standard Outlet Valve - Mechanical 2020

2020 Version spare button : EV494AA Push Button No Logo Long Rods Rolling Change 2020

2020 Version spare inlet valve : EW06267 Univalve BI Dfil 300mm Spare Rolling Change 2020

## CUSTOMER CARE HELPLINE

# 01482 496318

FAX LINE 01482 499611

email: [customercare@idealstandard.com](mailto:customercare@idealstandard.com)

**WW10002467**

ver. 1.0/01.22

---

We pursue a policy of continuing improvement in design and performance of our products. The right is, therefore, reserved to vary specifications without notice.