



Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservdelar / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Pieśe de schimb
 / Rendelhető alkatrészek / Запасні частини / Reservni delovi / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļu



XX = AA, AD...



Position

- 1 = A 960 333 XX
- 2 = A 960 590 XX
- 3 = A 962 594 NU
- 4 = A 961 820 XX
- 5 = A 960 800 XX
- 6 = A 960 529 XX
- 7 = A 960 492 NU
- 8 = A 962 335 NU
- 9 = A 963 004 NU
- 10 = A 960 512 NU
- 11 = A 961 819 NU
- 12 = A 960 556 NU
- 13 = A 960 516 NU
- 14 = A 960 517 NU
- 15 = A 960 520 NU
- 16 = A 963 033 NU




MOMENTS
 A 3920 ..





0811 / A 865 585
 (+ A 865 612)
 Made in Germany



Ideal Standard International BVBA
 Chaussée de Wavre, 1789 - box 15
 1160 Bruxelles
 Belgium

www.idealstandardinternational.com





	P	bar		MAX. 10		5		Q	(3 bar)
	T	°C		MAX. 80		65		I/min	20,5

