





Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb
 / Rendelhető alkatrészek / Запасні частини / Reservni delovi / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļu

XX = AA, AD ..




Position

- 1 = A 961 494 XX
- 4 = A 960 701 XX
- 5 = A 960 702 XX
- 6 = A 963 427 NU
- 7 = A 960 587 NU
- 10 = A 963 432 NU
- 11 = A 960 462 NU
- 12 = A 962 064 XX
- 13 = A 960 692 NU
- 15 = A 962 062 NU
- 16 = A 962 063 XX
- 20 = A 961 810 NU (2x)
- 22 = A 860 415 NU
- 24 = A 963 154 NU
- 26 = A 960 196 NU



ATTITUDE
A 4616 ..







1012 / A 866 023
 Made in Germany



Ideal Standard International BVBA
 Chaussée de Wavre, 1789 - box 15
 1160 Bruxelles
 Belgium

www.idealstandardinternational.com





	P	bar	MIN. 0,5	MAX. 5	Q (0,5 bar)
	T	°C	MAX. 80	65 40	