





Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb /
 Rendelhető alkatrészek / Запасні частини / Reservní deloví / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļu

XX = AA,AD



Position

- 1 = A 960 645 XX
- 3 = B 960 473 XX
- 5 = A 960 646 XX
- 9 = A 962 985 NU
- 19 = A 960 678 NU
- 21 = A 962 385 XX
- 22 = B 960 497 NU
- 23 = A 960 679 XX
- 26 = A 960 654 XX
- 29 = A 961 230 XX
- 30 = A 960 196 NU




ATTITUDE
 A 4617 ..

















0914 / A 866 051
 (+ A 865 612)
 Made in Germany



Ideal Standard International BVBA
 Corporate Village - Gent Building
 Da Vincilaan 2
 1935 Zaventem
 Belgium

www.idealstandardinternational.com





	P	bar	MIN. 0,1		MAX. 5	
	T	°C	MAX. 80		65 40	