





Ordering spares / Ersatzteil - Regelung / Pièces de rechange / Parti di ricambio / Lista de recambios / Onderdelen bestellen (NL/B) / Κωδικοί Ανταλλακτικών / Bestilling af reservedele / Beställning av reservdelar / Bestilling av reservedeler / Резервни части / Запчасти / Części zapasowe / Piese de schimb / Rendelhető alkatrészek / Запасні частини / Резервни делови / Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezerves daļas / Náhradní díly / Náhradné diely / Yedek parça siparişi / Nadomestni deli

XX = AA, AD, .....


- 1 - B 961548 XX
- 1a - B 961549 XX
- 3 - B 960583 XX
- 4 - A 861446 NU
- 5 - A 861247 NU - RH  
A 861246 NU - LH
- 7 - B 960486 XX
- 8 - A 961625 XX
- 9 - B 960166 XX
- 12 - A 961326 NU
- 14 - B 961342 XX
- 15 - B 960471 NU
- 16 - A 963173 NU
- 18 - B 960925 XX




Ideal Standard

**CERAFINE MODEL D**

08.2020 / B665986



**B C694 ..**







**B C695 ..**



Ideal Standard International NV  
Corporate Village – Gent Building  
Da Vincilaan 2  
1935 Zaventem  
Belgium  
<http://www.idealstandardinternational.com>





P bar	MAX. 10	3	0,2	Q (0.2 bar)
T °C	MAX. 80	65	40	I/min
				15
				8