






Ordering spares / Ersatzteil - Regelung / Pièces de rechange / Parti di ricambio / Lista de recambios / Onderdelen bestellen (NL/B) / Κωδικοί Ανταλλακτικών / Bestilling af reservedele / Beställning av reservdelar / Bestilling av reservedeler / Резервни части / Запчасти / Części zapasowe / Piese de schimb / Rendelhető alkatrészek / Запасні частини / Резервни делови / Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezerves daļas / Náhradní díly / Náhradné diely / Yedek parça siparişi / Nadomestni deli

XX = AA, AD, .....

- 1 - B 961580 XX
- 2 - B 960473 XX
- 3 - B 961438 XX
- 4 - B 961374 NU
- 5 - A 861181 NU
- 6 - A 861156 NU
- 7 - B 961582 NU
- 8 - A 960911 NU
- 9 - B 961793 XX
- 10 - B 960500 NU
- 11 - B 960712 XX
- 12 - A 962574 NU
- 13 - B 960255 NU
- 14 - A 963600 NU
- 15 - A 960944 NU
- 16 - B 960460 NU
- 17 - A 961817 NU
- 18 - B 960845 NU




CERALOOK




Ideal Standard





05.2022 / B565226

B D573 ..



Ideal Standard International NV  
Corporate Village – Gent Building  
Da Vincilaan 2  
1935 Zaventem  
Belgium  
<http://www.idealstandardinternational.com>





P	°C	°C	0	1	2	3	4	5
			°C	°C	°C	°C	°C	°C
50°C	15°C	15°C	50	49	44	40	35	33
65°C	15°C	15°C	65	63	57	50	44	40
85°C	15°C	15°C	85	83	74	64	56	50

