





Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb
 / Rendelhető alkatrészek / Зпасні частини / Reservni delovi / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļi

XX = AA, GN, ...

Pos.	Part No.
1	A 861 505 XX
2	A 861 506 XX
3	A 861 243 NU A 861 244 NU
4	A 861 507 NU
5	A 861 479 XX
6	B 960 389 NU
7	A 861 418 NU
8	B 960 432 NU
9	A 961 230 XX





Ideal Standard

CONCA


A 7445 ..





0820 / A 868 686



Ideal Standard International NV
 Corporate Village - Gent Building
 Da Vincilaan 2
 1935 Zaventem
 Belgium

www.idealstandardinternational.com





	P	bar			Q (3 bar)
	T	°C			l/min
					5