



Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /  
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /  
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /  
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb /  
 Rendelhető alkatrészek / Запасні частини / Reservní delovi / Резервни делови /  
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļu

XX= AA,AD, ..





**Position**

- 1 = A 962 068 XX
- 2 = A 963 667 NU
- 4 = A 961 485 XX
- 5 = A 961 667 NU (2x)
- 7 = A 962 715 NU
- 8 = A 963 372 NU
- 9 = A 960 145 NU
- 11 = A 960 421 NU  
A 960 196 NU
- 12 = A 963 157 NU (2x)
- 13 = A 963 916 NU
- 14 = A 960 133 NU
- 15 = A 960 205 NU




**MELANGE**  
**A 4277 ..**










0811 / A 865 817  
 (+ A 865 612)



Ideal Standard International BVBA  
 Chaussée de Wavre, 1789 - box 15  
 1160 Bruxelles  
 Belgium

www.idealstandardinternational.com





	<b>P</b>	bar	0,5		MAX. 10	1		<b>Q</b> (3 bar)
	<b>T</b>	°C			MAX. 80			<b>l/min</b>
					65	40		<b>13</b>