





Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /  
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /  
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /  
 Nadomestní deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb  
 / Rendelhető alkatrészek / Запасні частини / Reservni delovi / Резервни делови /  
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļu

XX = AA, AD ..


Position

- 1 = A 960 645 XX
- 3 = B 960 473 XX
- 5 = A 960 646 XX
- 9 = A 962 716 NU
- 17 = A 960 647 NU
- 21 = A 960 687 NU
- 23 = A 960 688 XX
- 28 = A 960 654 XX
- 31 = A 961 230 XX




**ATTITUDE**  
 A 4597 .. A 5536 ..


0615 / A 866 057  
 (+ A 865 612)  
 Made in Germany



**A 4597 ..**





















**A 5536 ..**



Ideal Standard International BVBA  
 Corporate Village - Gent Building  
 Da Vincilaan 2  
 1935 Zaventem  
 Belgium

[www.idealstandardinternational.com](http://www.idealstandardinternational.com)





	<b>P</b>	bar	MIN. 1.5		MAX. 5		<b>Q</b> (1.5 bar)
	<b>T</b>	°C	MAX. 80		65 55		<b>l/min</b>