








Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb /
 Rendelhető alkatrészek / Зарпасні частини / Резервни делови / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļu

Pos.	Part No.
1	F 960 850 AA
2	A 860 603 NU
3	F 960 854 AA
5	A 960 230 NU
6	F 960 855 NU
7	F 960 856 NU
9	A 961 114 NU
10	A 962 294 NU
11	F 960 843 NU
15	B 960 432 NU
16	F 960 857 AA
17	A 962 370 NU
18	A 962 215 AA
19	A 961 172 NU
20	A 961 230 AA




sottini

MELITO


A 6480 .. A 6481 ..
 A 6482 .. A 6483 ..

0116/ A 868 073
 (+ A 866 385)
 Made in Germany



A 6480 ..

A 6481 ..



A 6482 ..





A 6483 ..



Ideal Standard International NV
 Corporate Village - Gent Building
 Da Vincilaan 2
 1935 Zaventem
 Belgium

www.idealstandardinternational.com





P bar	MAX. 10 0,5	5 1		Q (3 bar) l/min 5
	T °C	MAX. 80		

