







Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /  
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /  
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /  
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb  
 / Rendelhető alkatrészek / Зпасні частини / Reservni delovi / Резервни делови /  
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļi

Pos.	Part No.
1	F 960 850 AA
2	A 860 603 NU
3	F 960 854 AA
5	A 960 230 NU
6	F 960 855 NU
7	F 960 856 NU
9	A 961 114 NU
10	A 962 294 NU
11	F 960 843 NU
15	B 960 432 NU
16	F 960 857 AA
17	A 962 370 NU
18	A 962 215 AA
19	A 961 172 NU
20	A 961 230 AA




	<b>P</b>	<b>bar</b>				
	<b>T</b>	<b>°C</b>				<b>l/min</b>
						<b>5</b>




sottini

**MELITO**  
**A 6486 .. A 6487 ..**

0116 / A 868 079  
 (+ A 866 385)  
 Made in Germany



**A 6486 ..**







**A 6487 ..**



Ideal Standard International NV  
 Corporate Village - Gent Building  
 Da Vincilaan 2  
 1935 Zaventem  
 Belgium

www.idealstandardinternational.com





	<b>P</b> bar	0,5		MAX. 10	1		<b>Q</b> (3 bar)
	<b>T</b> °C			MAX. 80			<b>l/min</b>
							5

